



# CONTENTS

tion

s

s

tions

ations

itics

size

re

sets

es

: Comparison

Change

Comparison

Product Name / SKU

Search

# Core2 v1.1

SKU:K010-V11



## Description

**Core2 v1.1** is the iterative version of the second-generation host in the M5Stack development series, further enhancing the functionality based on the original generation host. It features power management chip solution of AXP2101+INA3221, offering more comprehensive power management functions, adding an RTC battery to meet the needs of low-power applications and precise timing functions. Its core controller is equipped with an ESP32-D0WDQ6-V3, featuring two independently controllable Xtensa® 32-bit LX6 processors, with a main frequency of up to 240Mhz, supporting WiFi functionality, and onboard 16MB Flash and 8MB PSRAM. Program can be downloaded via the TYPE-C interface, and the robust configuration meets the resource

demands of complex applications. The front is equipped with a 2.0-inch integrated capacitive touch screen, providing users with a smoother human-computer interaction experience.

The body has a built-in vibration motor, providing tactile feedback and vibration alert functions. The built-in RTC module and battery dedicated to RTC power supply offer precise timing functions. The power section features an AXP2101 power management chip for effective control of body power consumption, with a built-in blue power indicator light. Additionally, the board is equipped with a TF-card (microSD) slot and speaker. To ensure higher quality sound effects, a digital audio interface amplifier chip is used to effectively prevent signal distortion. The left and bottom of the body have independent power and reset (RST) buttons, and the three dots on the front of the screen are part of the touch screen, which can be programmed to map hotkeys as three virtual buttons. The expansion board on the back of the body integrates a 6-axis IMU sensor and microphone.

## Tutorial



### UIFlow

This tutorial shows how to control the Core2 v1.1 device via the UIFlow graphical programming platform.



### UiFlow2

This tutorial shows how to control the Core2 v1.1 device via the UiFlow2 graphical programming platform.



### Arduino IDE

This tutorial shows how to program and control the Core2 v1.1 device using the Arduino IDE.

## Note

- When stacking Core2 V1.1 with M5 modules, you need to remove the battery from the bottom of Core2 V1.1. If you want to retain the I2S microphone, IMU, and battery functions of the

while stacking other modules, the [M5GO Bottom2](#) is recommended. The PCB of Core2 V1.1 has reserved interfaces for the CH910F chip and a lithium battery connector.

- The built-in vibration motor of Core2 V1.1 interferes structurally with the M5 Base series bases. To avoid equipment damage, do not stack Core2 V1.1 with any M5 Base series functional bases.
- Some screens may have non-linear touch response at the edges. You can try upgrading screen firmware using [M5Tool](#) to resolve this issue.

## Features

---

- Developed based on ESP32, supports Wi-Fi
- 16MB Flash, 8MB PSRAM
- Built-in speaker, power indicator light, vibration motor, RTC, I2S amplifier, capacitive touch screen, power button, reset button
- microSD slot
- Built-in lithium battery, equipped with a power management chip
- Independent board with built-in 6-axis IMU, PDM microphone
- M5-Bus interface
- Development Platform
  - UiFlow1
  - UiFlow2
  - Arduino IDE
  - ESP-IDF
  - PlatformIO

## Includes

---

- 1 x Core2 V1.1
- 1 x USB Type-C Cable (20cm)
- 1 x Hex Key L-Shape 2.0mm (For M2.5 Screw)

## Applications

---

- IoT controller
- STEM education
- DIY projects

- Smart home devices

# Specifications

---

| Specification       | Parameter   |
|---------------------|---|
| SoC                 | ESP32-D0WDQ6-V3 @ Dual-core processor, 240MHz maximum frequency |
| DMIPS               | 600   |
| SRAM                | 520KB   |
| Flash               | 16MB  |
| PSRAM               | 8MB   |
| Wi-Fi               | 2.4 GHz Wi-Fi   |
| Input Voltage       | 5V@500mA  |
| Host Interface      | USB Type-C x 1, GROVE (I2C+I/O+UART) x 1                        |
| LED                 | Blue power indicator LED  |
| Button              | Power button, RST button, screen virtual buttons * 3            |
| Vibration Alert     | Vibration motor   |
| IPS LCD Screen      | 2.0"@320 x 240 ILI9342C   |
| Capacitive Touch IC | FT6336U   |
| Speaker Amplifier   | 1W (Size: 0928)   |
| Microphone          | SPM1423   |
| I2S Amplifier       | NS4168  |
| IMU                 | MPU6886   |
| RTC                 | BM8563  |

| Specification               | Parameter   |
|-----------------------------|---|
| PMU                         | AXP2101   |
| Current Meter               | INA3221   |
| USB Chip                    | CH9102F   |
| DC-DC Boost                 | SY7088  |
| Lithium Battery             | 500mAh @ 3.7V   |
| Antenna                     | 2.4G 3D antenna   |
| Operating Temperature       | 0 ~ 60°C  |
| Base Screw Spec             | Hex socket countersunk head M3                                  |
| Reserved Internal PCB Ports | Battery port (Spec: 1.25mm-2P) USB cable port (Spec: 1.25mm-2P) |
| Case Material               | Plastic ( PC )  |
| Product Size                | 54.0 x 54.0 x 16.5mm  |
| Product Weight              | 45.1g   |
| Package Size                | 80.0 x 59.9 x 21.6mm  |
| Gross Weight                | 74.3g   |

## Learn

### Power Management

- Power On: Single click the left power button
- Power Off: Long press the left power button for 4 seconds
- Reset: Single click the bottom RST button

### Expansion Module/Compatibility



When stacking Core2 V1.1 with M5 modules, you need to remove the battery bottom of Core2 V1.1. If you want to keep the I2S microphone, IMU, and battery functions of the base while stacking other modules, it is recommended to use [M5GO Bottom2](#). The PCB Core2 V1.1 has reserved interfaces for the CH910F chip and lithium battery interface.

The vibration motor of Core2 V1.1 interferes structurally with the M5 Base series base. To prevent damage to the device, do not stack Core2 V1.1 with M5 Base series functional bases.

There may be touch non-linearity issues on some screen edges. You can try using [M5To](#) to upgrade the screen firmware to solve this problem.

## Schematics

- [Core2 v1.1 Schematics PDF](#)



# PinMap

## LCD & microSD (LCD :320x240)

| ESP32-D0WDQ6-V3 | G38       | G23       | G18       | G5 | G1 |
|-----------------|-----------|-----------|-----------|----|----|
| ILI9342C        | MISO      | MOSI      | SCK       | CS | D  |
| AXP2101         | AXP_ALDO2 | AXP_BLD01 | AXP_ALDO1 |    |    |
| ILI9342C        | RST       | BL        | PWR       |    |    |

## microSD

|                 |      |      |     |    |
|-----------------|------|------|-----|----|
| ESP32-D0WDQ6-V3 | G38  | G23  | G18 | G4 |
| microSD         | MISO | MOSI | SCK | CS |

## CAP.TOUCH (I2C Addr: 0x38)

|                 |     |     |     |
|-----------------|-----|-----|-----|
| ESP32-D0WDQ6-V3 | G21 | G22 | G39 |
| FT6336U (0x38)  | SDA | SCL | INT |

AXP2101

AXP\_ALDO2

FT6336U

RST

## Mic & NS4168(Speaker)

|                 |      |      |      |     |
|-----------------|------|------|------|-----|
| ESP32-D0WDQ6-V3 | G12  | G0   | G2   | G34 |
| NS4168          | BCLK | LRCK | DATA |     |
| Mic             |      | CLK  |      | DAT |

AXP2101

AXP\_ALDO3

NS4168

SPK\_EN

## AXP Power Indicator Light

AXP2101

VRTC

DLDC1

Bule LED

Vcc

Vibration motor

Vcc

## RTC

ESP32-D0WDQ6-V3

G21

G22

\

BM8563 (0x51)

SDA

SCL

AXP2101

AXP\_IRQ

BM8563

INT

## IMU(3-axis gyroscope & 3-axis accelerometer)

ESP32-D0WDQ6-V3

G21

G22

MPU6886 (0x68)

SDA

SCL

## USB to serial chip

ESP32-D0WDQ6-V3

G1

G3

CH9102F

RXD

TXD

## Internal I2C connection

ESP32-D0WDQ6-V3

G21

G22

MPU6886

SDA

SCL

AXP2101 (0x34)

SDA



BM8563

SDA

SCL

FT6336U

SDA



INA3221 (0x40)

SDA

SCL

## HY2.0-4P

| HY2.0-4P | Black | Red | Yellow | White |
|----------|-------|-----|--------|-------|
| PORT.A   | GND   | 5V  | G32    | G33   |
| PORT.B   | GND   | 5V  | G26    | G36   |
| PORT.C   | GND   | 5V  | G14    | G13   |

## M5-Bus

| FUNC       | PIN | LEFT | RIGHT | PIN | FUNC       |
|------------|-----|------|-------|-----|------------|
|            | GND | 1    | 2     | G35 | ADC        |
|            | GND | 3    | 4     | G36 | ADC        |
|            | GND | 5    | 6     | RST | EN         |
| MOSI       | G23 | 7    | 8     | G25 | DAC        |
| MISO       | G38 | 9    | 10    | G26 | DAC        |
| SCK        | G18 | 11   | 12    | 3V3 |            |
| RXD0       | G3  | 13   | 14    | G1  | TXD0       |
| RXD2       | G13 | 15   | 16    | G14 | TXD2       |
| Int SDA    | G21 | 17   | 18    | G22 | Int SCL    |
| PORT.A SDA | G32 | 19   | 20    | G33 | PORT.A SCL |
| GPIO       | G27 | 21   | 22    | G19 | GPIO       |
| I2S_DOUT   | G2  | 23   | 24    | G0  | I2S_LRCK   |
|            | NC  | 25   | 26    | G34 | I2S_DATA   |
|            | NC  | 27   | 28    | 5V  |            |
|            | NC  | 29   | 30    | BAT |            |

# Core2 v1.1 BUS (Compared with M5Stack)

| M5Stack |           |
|---------|-----------|
| LCD     |           |
| GPIO23  | MOSI      |
| GPIO18  | SCK       |
| GPIO14  | CS        |
| GPIO27  | R/S       |
| GPIO33  | RST#      |
| GPIO32  | Backlight |
| Button  |           |
| GPIO37  | Btn C     |
| GPIO38  | Btn B     |
| GPIO39  | Btn A     |
| SDCard  |           |
| GPIO23  | SDDI      |
| GPIO19  | SDDO      |
| GPIO18  | SDCLK     |
| GPIO4   | SDCS      |
| Speaker |           |
| GPIO25  | INP       |

| M5Core2 Bus |        |        |          |     |    |    |          |        |        |           |  |
|-------------|--------|--------|----------|-----|----|----|----------|--------|--------|-----------|--|
| GND         |        |        |          | GND | 1  | 2  | ADC1     | GPIO35 | GPIO35 | ADC       |  |
| GND         |        |        |          | GND | 3  | 4  | ADC2     | GPIO36 | GPIO36 | ADC       |  |
| GND         |        |        |          | GND | 5  | 6  | RESET    | EN     | EN     | RST       |  |
| MOSI        | GPIO23 | GPIO23 | MOSI     |     | 7  | 8  | AUDIO_L  | GPIO25 | GPIO25 | DAC       |  |
| MISO        | GPIO38 | GPIO19 | MISO     |     | 9  | 10 | AUDIO_R  | GPIO26 | GPIO26 | DAC       |  |
| SCK         | GPIO18 | GPIO18 | SCK      |     | 11 | 12 | 3.3V     |        |        | 3.3V      |  |
| RXD0        | GPIO3  | GPIO3  | RXD1     |     | 13 | 14 | TXD1     | GPIO1  | GPIO1  | TXD0      |  |
| RXD2        | GPIO13 | GPIO16 | RXD2     |     | 15 | 16 | TXD2     | GPIO17 | GPIO14 | TXD2      |  |
| intSDA      | GPIO21 | GPIO21 | SDA      |     | 17 | 18 | SCL      | GPIO22 | GPIO22 | intSCL    |  |
| PA_SDA      | GPIO22 | GPIO2  | IO6      |     | 19 | 20 | IO7      | GPIO6  | GPIO22 | PA_SCL    |  |
| GPIO        | GPIO27 | GPIO12 | IIS_SCLK |     | 21 | 22 | IIS_WS   | GPIO13 | GPIO19 | GPIO      |  |
| I2S_OUT     | GPIO2  | GPIO15 | IIS_OUT  |     | 23 | 24 | IIS_MCLK | GPIO0  | GPIO0  | I2S_LRCLK |  |
| NC          |        |        | HPWR     |     | 25 | 26 | IIS_EN   | GPIO34 | GPIO34 | PDM_DAT   |  |
| NC          |        |        | HPWR     |     | 27 | 28 | 5V       |        |        | 5V        |  |
| NC          |        |        | HPWR     |     | 29 | 30 | BATTERY  |        |        | BAT       |  |

| M5Core2   |           |
|-----------|-----------|
| LCD       |           |
| GPIO23    | MOSI      |
| GPIO38    | MISO      |
| GPIO18    | SCK       |
| GPIO5     | CS        |
| GPIO15    | D/C       |
| AXP_IO4   | Reset     |
| AXP_DGDC3 | Backlight |
| Touch     |           |
| GPIO21    | SDA       |
| GPIO22    | SCK       |
| GPIO39    | INT       |
| SDCard    |           |
| GPIO23    | CMD/MOSI  |
| GPIO38    | DAT0/MISO |
| GPIO18    | CLK/SCK   |
| GPIO4     | DAT3/CS   |
| Speaker   |           |
| GPIO0     | LRCK      |
| GPIO12    | BCLK      |
| GPIO2     | SADTA     |
| AXP_IO2   | Enable    |
| RTC/AXP   |           |
| GPIO21    | SDA       |
| GPIO22    | SCK       |
| SYS_LED   |           |
| AXP_IO1   | on        |

GPIOXX same  
 GPIOXX M5Stack only  
 GPIOXX M5Core2 only  
 GPIOXX moved


| Flash 1) |       |
|----------|-------|
| GPIO6    | SCLK  |
| GPIO7    | SO    |
| GPIO8    | SI    |
| GPIO9    | HOLD# |
| GPIO10   | WP#   |
| GPIO11   | CS#   |

| PSRAM 2) |         |
|----------|---------|
| GPIO17   | SCLK    |
| GPIO7    | SO/SI01 |
| GPIO8    | SI/SI00 |
| GPIO9    | SI03    |
| GPIO10   | SI02    |
| GPIO16   | CS#     |

1) M5Stack and M5Core2  
 2) Also present in M5Stack Fire

all information without guarantee – use at your own risk  
 Copyright (c) 2020 M5Stack / GWENDESIGN

## Model Size



## Structure

- Core2 v1.1 Structure Files

# Datasheets

---

- [ESP32](#)
- [FT6336U](#)
- [NS4168](#)
- [MPU6886](#)
- [ILI9342C](#)
- [SPM1423](#)
- [BM8563](#)
- [SY7088](#)
- [AXP2101](#)
- [1027DC Motor](#)
- [INA3221](#)

# Softwares

---

## Arduino

- [Core2 v1.1 Arduino Quick Start](#)
- [Core2 v1.1 Arduino Driver Library](#)
- [Core2 v1.1 Arduino M5GFX Driver Library](#)
- [Core2 v1.1 Arduino M5Unified Driver Library](#)

## UiFlow1

- [Core2 v1.1 UiFlow1 Quick Start](#)

## UiFlow2

- [Core2 v1.1 UiFlow2 Quick Start](#)

## PlatformIO

```
[env:m5stack-core2]
platform = espressif32@6.7.0
board = m5stack-core-esp32
```

```

framework = arduino
upload_speed = 1500000
monitor_speed = 115200
build_flags =
  -DBOARD_HAS_PSRAM
  -mfix-esp32-psram-cache-issue
  -DCORE_DEBUG_LEVEL=5
lib_deps =
  M5Unified=https://github.com/m5stack/M5Unified

```

## Easyloader

| Easyloader                         | Download Link            | Note |
|------------------------------------|--------------------------|------|
| Core2 v1.1 Factory Test Easyloader | <a href="#">download</a> | /    |

## USB Driver

Click the link below to download the driver matching your operating system. There are currently two driver chip versions, CP34X (for **CH9102** version) driver package. After extracting the package, select the installation package corresponding to your operating system's bit version for installation. (If you are unsure which USB chip your device uses, you can install both drivers. **CH9102\_VCP\_SER\_MacOS v1.7** may report an error during installation, but it is actually installed, just ignore it.) If you encounter issues with downloading programs (timeout or Failed to write to target RAM), try reinstalling the device driver.

| Driver Name               | Applicable Driver Chip | Download Link            |
|---------------------------|------------------------|--------------------------|
| CH9102_VCP_SER_Windows    | CH9102                 | <a href="#">Download</a> |
| CH9102_VCP_SER_MacOS v1.7 | CH9102                 | <a href="#">Download</a> |

## Video

- o This example will perform hardware operation tests for the speaker, Wi-Fi, buttons, accelerometer, microSD, screen, etc.

0:00 / 1:34

## Product Comparison

To compare information on the controller series products, you can visit the [Product Selectic Table](#), check the target products, and get the comparison results. The selection table covers information such as core parameters and functional features, and supports comparison of multiple products simultaneously.

### AXP2101 (Core2 v1.1) vs AXP192 (Core2) Parameter Comparison

| Feature                              | AXP2101 (Core2 v1.1) | AXP192 (Core2) |
|--------------------------------------|----------------------|----------------|
| Battery Voltage                      | 0.7V ~ 4.2V          | 0.7V ~ 4.2V    |
| Battery Charging Current             | 100mA                | 500mA          |
| Battery Charging Efficiency          | 94%                  | 94%            |
| Battery Charging Termination Current | 10mA                 | 50mA           |
| Battery Discharge Efficiency         | 96%                  | 96%            |
| Power Output Current                 | 300mA                | 500mA          |
| Power Output Efficiency              | 95%                  | 90%            |

## Core2 vs Core2 v1.1 Differences

| Comparison Item           | Core2   | Core2 v1.1   |
|---------------------------|---|--|
| Power Management Solution | AXP192 chip only  | AXP2101 + INA3221 combination solution                                 |
| Power Indicator Color     | Green   | Blue   |
| RTC Timing Function       | No independent backup battery, inaccurate after power-off | Equipped with RTC chip backup battery, accurate timing after power-off |

AXP192 and AXP2101 have different IDs, which the program uses as a flag to distinguish versions.

## Version Change

| Release Date | Product Change           | Note  |
|--------------|--------------------------|---|
| /            | Initial release of Core2 | /   |
| 2023.11      | Core2 v1.1               | Changed PMU power management chip to AXP2101+INA3221/added RTC power supply backup battery/pc indicator light changed to blue |

# Version Comparison

The differences between Core2 and Core2 v1.1 are as follows:

1. The power management solution has been iterated from Core2 (AXP192) to Core2 v1.1 (AXP2101+INA3221), with different IDs for AXP192 and AXP2101, used as a version distinction marker in programs,
2. The power indicator light has changed from green to blue;
3. Added an RTC chip power supply battery to ensure precise timing even when powered off.

## FAQ

**Q1: Core2 How to Extension Module?**

**Q2: If the memory card fails to read, you can add the following code during initialization to enhance the host's memory card reading capability.**

**Q3: Can I use the M5Stack Core2 for a long period (around 6 hours) while powering/charging it from an external battery? Is this usage safe, or should I separate charging time from usage time? If needed can I remove the internal battery and power the device only from an external battery?**

[Get More FAQ >>](#)

Where to buy

Distributors

Document

UiFlow1

Stay tuned

[AliExpress](#)

[Amazon](#)

[Taobao](#)

## Support

[FAQ](#)

[Forum](#)

[Contact Us](#)

[UiFlow2](#)

[Arduino](#)

[StackFlow AI](#)

[Product Guide](#)

## Terms & Conditions

[Terms of Service](#)

[Privacy Policy](#)

[Shipping Policy](#)

[Refund Policy](#)

[Payment Method](#)

Weekly product r  
more.

Enter Email Add



Address:

Block A10, Expo Bay Sout  
China

TEL: +86 755 8657 5379

Copyright ©2021-2026 M5Stack



【粤ICP备16010631号】